




HOW TO MEASURE ARROW FOR CUTTING

Arrow length is measured from the end of the insert
(front) to the end of the nock **(back)**.



If you have questions, call the shop at (785) 467 - 3600.
Custom arrows are non-refundable.

START HERE



End of Insert
(Front of Arrow)

IMPORTANT

Measure in a
straight line
along the arrow.

END HERE



End of Nock
(Back of Arrow)

STEPS:

- 1 Place the arrow on a flat surface.
- 2 Align the tape measure with the end of the insert.
- 3 Measure straight to the end of the nock.



This is the full arrow length.
**Use this measurement
for cutting.**

EXAMPLE:

Shown arrow measures
34 1/4 inches
(Insert end to nock end)

